

Matt Sweeney Special Effects, Inc,
14201 Bessemer Street, Van Nuys, California 91401
(818) 902-9354 • FAX (818) 902-1513
www.sweeney-special-effects.com

READ THIS NOW**READ THIS NOW**READ THIS NOW

INSTRUCTIONS FOR GLASS POPPERS

This device is for use by experienced special effects persons **ONLY. ALWAYS** test before using. **ALWAYS** inspect before using. Use at your own risk. If you have any doubts about the condition of this device, we will inspect it for you. Be careful and **THINK**.

These glass breakers are for use by experienced special effects personell **only**. Use at your own risk. We make no guarantee as to performance. During use, glass breakers may shoot glass fragments from the working end. Use eye protection for anyone nearby.

Due to the unpredictable nature of tempered glass, it is strongly recommended that two or more glass breakers be used for each pane and that they be solidly affixed. If you need to glue the breaker to the glass, it is *not recommended to use cyanoacrylic **kicker***, as it greatly weakens the bond. A rare earth magnet on the other side of the glass is a great way to hold the breaker immobile while cyanoacrylic glue cures. Do not get any glue in the nail hole! Use D-60-3 or T12-3 minimum. Large glass breakers use a Hilti nail (Part # X-DS 27P10), Small glass breakers use a smaller Hilti nail (Part # X-U 16 P8). The nail must be replaced for each shot. **They come with a plastic collar which must be removed before use.**

Any questions, call us. Shop (818) 902-9354 Home (818) 761-2380